

## HOW IT WORKS


## **FAST-STOP™** Blast Hose Safety Relief System



Path Of Air & Abrasive During Blowdown



All air & abrasive exits through nozzle when the control handle is released.




**Automat** 

Plunger

Valve








## FAST-STOP™ System

Only a small amount of air & abrasive exits through the nozzle when the control handle is released.



The majority of air & abrasive exits through the muffler where it is slowed and diffused.